

Molybdenum (Mo) Test Kit

1 drop = 2, 5, 20 or 50 ppm

TK3290-Z

white caps

KIT COMPONENTS:

MO1546-B	Molybdenum Titrating Solution, 60 mL
MO1525-B	Molybdenum Buffer, 60 mL
MO1543-B	Molybdenum Indicator Solution, 60 mL
SY-2001-P	Syringe, 1 mL (3x)
SY-2005-P	Syringe, 5 mL
VL-1005-V	Vial, 10-50 mL (4x)

INTERFERENCES: High concentrations of phosphonate can create positive interferences. High concentrations of nitrites can cause negative interferences.

SAFETY TIPS:



Wear
Gloves



Use Eye
Protection



Read
SDS

TESTING TIPS:



Collect
Accurate
Sample



Hold
Bottles
Vertically



Ensure
Proper
Lighting

ATTENTION: As necessary, calibrate this kit against a known standard made with plant / make-up water. Be sure to collect a representative sample.



1 Rinse a vial 3 times with sample and select a sample size based on the desired drop equivalency.

For smaller sample sizes, use syringe to collect the sample and dilute to 10 mL with Molybdenum free water.

1 drop = 2 ppm	25 mL sample
1 drop = 5 ppm	10 mL sample
1 drop = 20 ppm	2.5 mL sample
1 drop = 50 ppm	1 mL sample

Fill a second vial with 25 mL of distilled, deionized or molybdenum free tap water.

2 Use the 1 mL syringe to add 0.5 mL of Molybdenum Buffer (MO1525) to each sample vial. Swirl the vials to mix.



STEP 1



STEP 3

3 Use the other 1 mL syringe to add 0.5 mL of Mo Indicator Solution (MO1543) to the sample vial and swirl to mix.

4 Add Molybdenum Titrating Solution (MO1546) to the vial containing your sample. Add one drop at a time while swirling. Count the number of drops until the sample color matches the color of the blank vial or until no further color change occurs.



STEP 4

Multiply number of drops by equivalence factor from step 1. Record result as ppm Molybdenum (Mo).

Multiply ppm Molybdenum by 1.7 to express result as ppm Molybdate (MoO_4).

NOTE: Mo Indicator Solution (MO1543) has a limited shelf life. An alternate kit, TK3279, is available with a stable, two-part reagent system.