

# Sodium Hypochlorite Test Kit

1 drop = 0.5% as NaClO / 1 mL

## TK1139-Z

orange caps

### KIT COMPONENTS:

SA1940-A	Sulfuric Acid 50%, 30 mL
PI1450-B	Potassium Iodide 50%, 60 mL
ST5010-B	Starch Indicator Solution 1%, 60 mL
ST2985-B	Hypochlorite Titrant, 60 mL
SY-2001-P	Syringe, 1 mL
VL-0525-V	Vial, 5-25 mL

**INTERFERENCES:** All oxidizers, including Bromine, are positive interferences for this test. Interferences include, a pH over 8, total hardness over 1000 ppm, sulfate over 1000 ppm, total alkalinity over 150 ppm, any concentration of nitrite, nitrate over 200 ppm, silica dioxide over 50 ppm, copper over 10 ppm, any concentration of ferrous iron (Fe<sup>2+</sup>), and ferric iron (Fe<sup>3+</sup>) over 5 ppm.

TK1139-Z-INST REV 01/17

### SAFETY TIPS:



Wear  
Gloves



Use Eye  
Protection



Read  
SDS

### TESTING TIPS:



Collect  
Accurate  
Sample



Hold  
Bottles  
Vertically




Ensure  
Proper  
Lighting

**ATTENTION:** As necessary, calibrate this kit against a known standard made with plant / make-up water. Be sure to collect a representative sample.

It is important that each reagent be added and then mixed well for at least 5 seconds before the addition of the subsequent reagent.




**1** Rinse vial three times with sample to be tested. Using the syringe **fill vial with 1 mL of the sample.** Dilute to the 10 mL mark with DI water.



STEP 1


**2** Add **20 drops of Potassium Iodide 50%** (PI1450) and swirl 5 seconds to mix.



STEP 3

**3** Add **3 drops of Sulfuric Acid 50%** (SA1940) and swirl 5 seconds to mix. Sample will turn yellow or brown if chlorine is present.


**4** Add **Hypochlorite Titrant** (ST2985) one drop at a time while swirling. Count the drops until the sample turns a pale yellow.



STEP 4

**5** Add **5 drops of Starch Indicator Solution 1%** (ST5010) and swirl 5 seconds to mix. Sample should turn dark blue.

**6** Add **Hypochlorite Titrant** (ST2985) one drop at a time while swirling. Count the drops until the sample turns colorless. Add the total number of drops (step 4 & 6) and multiply by the chosen factor.



STEP 5

# drops x 0.5 = % NaClO