

# pH Residue Test

**TK6200-Z**  
red caps

## KIT COMPONENTS:

DW4000-B	DI Water, 60 mL
SR2005-B	Sour Tester, 60 mL
CS5400	Cotton Swabs (2 pack), 100 swabs

## SAFETY TIPS:



Wear  
Gloves



Use Eye  
Protection



Read  
SDS

## TESTING TIPS:



Collect  
Accurate  
Sample



Hold  
Bottles  
Vertically



Ensure  
Proper  
Lighting

**ATTENTION:** Run this test on plant water to identify possible interferences.



**1 Add 2 drops of DI Water**  
(DW4000) to the swab.



STEP 1

**2 Swab a 4" x 4" area** of the surface you are testing.










STEP 2

**3 Add 1 to 2 drops of Sour Tester** (SR2005) **onto the swab.** Compare the color change to the chart below.



STEP 3

	Blue	High Alkaline
	Green	Slightly Alkaline
	Yellow-Green	Neutral
	Green-Yellow	Slightly Acidic - 6.5 pH
	Yellow	6.0 pH
	Orange - Orange-Red	5.5 to 4.5 pH
	Red-Orange Red	Less than 4.5 pH